

# Breathing Apparatus



Pre-use, periodic checks

## OPERATIONAL CHECKS

1. Inspect assembly
2. Open cylinder – No Leaks
3. Cylinder contents ( $> 80\%$ )
4. Close cylinder - Low pressure leaks ( $< 5$  bar/min)
5. Whistle (40 - 60 bar)

## DONNING CHECKS

1. Cylinder contents (above 80%)
2. Mask positive pressure: Don mask & inhale
3. Close cylinder: Whistle (40 - 60 bar)
4. Mask seal/leak: Suction & hold 5 - 10s

[www.vitalsafety.com.au](http://www.vitalsafety.com.au)